

Tutorial 2

Comparative analysis of structural changes of the P16 protein (CDKN2A gene) wild type (WT) with mutants:

1. Analysis using basic MD metrics — RMSD, Rg, RMSF :

After the initial relaxing 200 ns production run, we evaluate the protein trajectory using the basic MD analysis metrics:

1.1 RMSD (оценка стабильности структуры во времени)

```
gmx rms -s md_200ns.tpr -f md_200ns_fit.xtc -o rmsd.xvg -tu ns
```

Groups:

Fit group → 1(Protein)

RMSD group → 1(Protein)

-s md_200ns.tpr — input tpr file (reference structure + parameters)

-f md_200ns_fit.xtc — trajectory after centering and PBC correction

-o rmsd.xvg — output file with RMSD over time

-tu ns — output time in nanoseconds (ns) instead of ps

Output file:

rmsd.xvg — RMSD(t) plot over the entire 200 ns trajectory.

Plot the .xvg graphs using any convenient tool (xmgrace, Python, Excel, etc.):

Output the statistics:

```
gmx analyze -f rmsd.xvg
```

1.2 Radius of Gyration (Rg)

```
gmx gyrate -s md_200ns.tpr -f md_200ns_fit.xtc -o gyrate.xvg
```

Group: Protein

Output file:

gyrate.xvg — change in protein compactness (Rg) over time.

Statistics:

```
gmx analyze -f gyrate.xvg
```

1.3 RMSF (per-residue fluctuations)

```
gmx rmsf -s md_200ns.tpr -f md_200ns_fit.xtc -o rmsf.xvg -res
```

Select the group: Protein

Output file:

rmsf.xvg — RMSF for each protein residue (156 aa).

Statistics:

```
gmx analyze -f rmsf_WT.xvg
```

2. Comparative analysis

As the wild-type (WT) template, we use the last frame (PDB) of the initial 200 ns production molecular dynamics run, taken from the centered trajectory(.xtc).

The resulting structure is cleaned of water molecules and ions, after which it is used as the starting structure for performing *in silico* mutagenesis (using third-party software, e.g., ChimeraX, Maestro Schrödinger).

(Files: **p16_p48l_h83y.pdb**, **p16_r131p_g55c.pdb**)

The mutations selected for comparison with WT correspond to real clinical cases and were chosen based on patient data available on cBioPortal — an international platform for the analysis of cancer genomics data.

Mutations:

P48L + H83Y: https://www.cbioportal.org/patient?sampleId=P-0006661-T01-IM5&studyId=pdac_msk_2024

R131P + G55C: https://www.cbioportal.org/patient?sampleId=P-0003222-T01-IM5&studyId=lung_msk_2017

Both the mutants and the WT undergo the standard pipeline followed by a 200 ns production run (as described in Tutorial 1).

2.1 Comparison using basic metrics (RMSD, Rg, RMSF):

Use the commands described in the previous section (`gmx rms`, `gmx gyrate`, `gmx rmsf`). Combine the plots (the .xvg files) using any convenient method (xmgrace, Python, Excel, etc.).

Using `gmx analyze` collect the data into a similar table for further comparison:

Белок	RMSD Avg	RMSD Std	RMSF Avg	RMSF Std	Rg Avg	Rg Std
WT						
P48L/H83Y						
R131P/G55C						

2.2 Protein Energy:

```
gmx energy -f WT.edr -o WT_energy.xvg
```

```
gmx energy -f P48L_H83Y.edr -o P48L_H83Y_energy.xvg
```

```
gmx energy -f R131P_G55C.edr -o R131P_G55C_energy.xvg
```

- **Temperature** should fluctuate around the target value (e.g., 300 K) with RMSD ~1–5 K and without noticeable drift.
- **Pressure in the NPT** ensemble exhibits large fluctuations (RMSD ~50–500 bar); evaluation is based on the average value, which should be close to 1 bar.
- **Potential energy** should be stable, fluctuating around a mean value with minimal drift relative to $|E|$.
- **Tot-Drift** should be small; significant values indicate numerical instability of the simulation.

2.3 Intra-protein H-bonds:

Look at the average number of hydrogen bonds over the entire trajectory

Example command (WT):

```
gmx hbond -s WT.tpr -f md_200ns_fit.xtc -num WT_hbnum_PP.xvg -WT_hbonds_PP.ndx
```

-s WT.tpr — input tpr file with system topology and parameters

-f md_200ns_fit.xtc — trajectory

-num WT_hbnum_PP.xvg — output number of hydrogen bonds over time (Protein–Protein)

-o WT_hbonds_PP.ndx — save the list of all donor–acceptor pairs (index file)

Select: group "Protein"

Output files:

WT_hbnum_PP.xvg — time evolution of the number of Protein–Protein hydrogen bonds (time → H-bond count)

WT_hbonds_PP.ndx — complete list of donor–acceptor pairs within the protein

Result check:

```
gmx analyze -f WT_hbnum_PP.xvg
```

2.4 DSSP analysis (secondary structure):

* mkdssp must be pre-installed

Example command (WT):

```
gmx dssp -s WT.tpr -f md_200ns_fit.xtc \  
-o WT_dssp.dat -num WT_dssp_num.xvg \  
-sel 'group "Protein"'
```

gmx dssp — calculation of protein secondary structure (DSSP)

-s WT.tpr — system topology

-f md_200ns_fit.xtc — centered trajectory without PBC artifacts

-o WT_dssp.dat — DSSP annotation by frames and residues

-num WT_dssp_num.xvg — numerical statistics of H/E/C over time

-sel 'group "Protein"' — analyze protein only

Output:

WT_dssp.dat — secondary structure assignment for analysis and plotting

WT_dssp_num.xvg — control statistics

*For analysis and visualization of the protein secondary structure over time, you can use the script `sse_P16.ipynb`

2.5 PCA (Principal Component Analysis) = analysis of the principal components of motion.

Compute the covariance matrix of atomic positional fluctuations → calculate its eigenvectors (PC1, PC2, PC3 ...).

Example command (WT):

```
gmx covar \  
-s WT.tpr \  
-f md_200ns_fit.xtc \  
-o WT_eigenval.xvg \  
-v WT_eigenvec.trr \  
-av WT_average.pdb \  
-b 100000
```

Select a group: 4

Selected 4: 'Backbone'

- s WT.tpr — system topology
- f md_200ns_fit.xtc — centered trajectory without PBC artifacts
- o WT_eigenval.xvg — eigenvalues (contribution of each mode)
- v WT_eigenvec.trr — eigenvectors (principal motions)
- av WT_average.pdb — average protein structure
- b 100000 — start analysis from 100 ns (initial relaxation is discarded)

Output:

WT_eigenval.xvg — mode spectrum (PCA)

WT_eigenvec.trr — trajectory of principal components

WT_average.pdb — average structure

PCA 1 vs 2 :

This is the projection of the trajectory onto the first and second principal components (PC1 and PC2). It shows the main conformational landscape.

Example command (WT):

```
gmx anaeig \
-v WT_eigenvec.trr \
-s WT.tpr \
-f md_200ns_fit.xtc \
-2d WT_2D_PC1_PC2.xvg \
-b 100000 \
-first 1 \
-last 2
```

Select a group: 4/4

Selected 4: 'Backbone'

- v WT_eigenvec.trr — eigenvectors from gmx covar
- s WT.tpr — system topology
- f md_200ns_fit.xtc — centered trajectory
- 2d WT_2D_PC1_PC2.xvg — projection of the trajectory onto PC1–PC2
- b 100000 — start analysis from 100 ns
- first 1 — first principal component (PC1)
- last 2 — second principal component (PC2)

Output:

WT_2D_PC1_PC2.xvg — 2D conformational landscape (PC1 vs PC2)

PCA 1 vs 3 :

Reveals additional / secondary motions that may not be visible in PC1–PC2 (alternative PCA projection).

Example command (WT):

```
gmx anaeig \
-v WT_eigenvec.trr \
-s WT.tpr \
-f md_200ns_fit.xtc \
-2d WT_2D_PC1_PC3.xvg \
-b 100000 \
-first 1 \
-last 3
```

Select a group: 4/4

Selected 4: 'Backbone'

Plot the graphs. They can be overlaid on top of each other

2.6 ProLif is a library for analyzing interactions in MD trajectories.

Analysis of MD trajectories that shows which amino acids interact with each other, what types of contacts they form, and how often over time; it is needed to quantitatively compare interactions in WT and mutants and understand which structural contacts are preserved, lost, or newly formed.

Detailed tutorial here: <https://prolif.readthedocs.io/en/stable/source/tutorials.html>

Example calculation for our trajectories - **P16_prolif.ipynb**

2.7 Visual analysis of trajectories

For visualization, we will use **VMD**.

After completing the MD simulation, first load the structure, then overlay the trajectory. To do this, launch VMD, open **File → New Molecule**, and load the structure file (.gro). Then, in the same window, click **Load Files** and add the trajectory file (.xtc). The trajectory will automatically play as an animation over the original structure.

In VMD, the display style is configured via **Graphics → Representations**: typically, a representation is created with the selection **protein** and the **NewCartoon** drawing method enabled, colored by secondary structure. Water can either be completely hidden by setting the selection to **not water**, or displayed separately in a simplified form (e.g., **Lines** or **Points**) to avoid cluttering the visualization.

The visualization can be recorded using standard screen recording tools.

Official VMD tutorials:

<https://www.ks.uiuc.edu/Training/Tutorials/vmd/tutorial-html/>

<https://www.ks.uiuc.edu/Training/Tutorials/vmd-imgmv/imgmv/imgmv-tutorial.pdf>